









INTRO PROFI


SCHUIFDEUR_PORTE COULISSANTE

20053484 - 20053485





3 x1	4 x2	5 ST3.5x25 x4	6 x6	7 x6	8 ST4x40 x6	9 x1
10 x1	12 x1	20 21 x1	22 23 x1	24 x1		





Om rechtse deur links te monteren:

- * demonteer de wieltjes
- * draai het glas
- * monteer de wieltjes opnieuw


Pour monter la porte droite à gauche:

- * Retirer les roulettes
- * Tourner le verre
- * Remonter les roulettes



R / D







b






L / G













③



④








Note: When adjust the door,
ONLY need to loosen the
screw a little bit, DON'T
loosen the screw completely.



Opmerking: Wanneer u de
deur aanpast, moet u alleen
de schroef een klein beetje
losdraaien.

Remarque: Lors du réglage de
la porte, ne desserrez que
légèrement la vis.







⑧







⑨






10





Note: When adjust the door, ONLY need to loosen the screw a little bit, DON'T loosen the screw completely.


Opmerking: Wanneer u de deur aanpast, moet u alleen de schroef een klein beetje losdraaien.

Remarque: Lors du réglage de la porte, ne desserrez que légèrement la vis.






11





12



13

